


← IBM
X1

CERX	CON
STR0B	1
D0	2
D1	3
D2	4
D3	5
D4	6
D5	7
D6	8
D7	9
ACKMLG	10
BUSY	11
PE	12
SLCT	13
AUTOFD	14
INIT	15
ERROR	16
SLCTIN	17
GND	18
GND	19
GND	20
GND	21
GND	22
GND	23
GND	24
GND	25

PRINTER →
X2

CON	CERX
1	STR0B
2	D0
3	D1
4	D2
5	D3
6	D4
7	D5
8	D6
9	D7
10	ACKMLG
11	BUSY
12	PE
13	SLCT
14	AUTOFD
15	INIT
16	ERROR
17	SLCTIN
18	GND
19	GND
20	GND
21	GND
22	GND
23	GND
24	GND
25	GND



RAINBOW
SRB0612
9741L59225
12804-000000-8040

W W W . d i a k o m . u r r